



Hand Wash Unit Installation Instructions



1 Drill 1/2" hole in toilet tank using molded indentation as a guide.



2 Place unit inside....Insert clear tubing from Wash Unit into toilet tank.



3 Mark and measure holes for rivets on back side of Wash Unit.

Tools Required:

- Drill
- 1/2" Drill Bit
- Tape Measure
- Rivet Gun



4 Locate holes on the outside of the toilet to align with the holes in the Wash Unit. Drill holes from outside of toilet into wash unit.

5 Secure Hand Wash Unit in place with supplied rivets



6 Push tank against inside wall. Mark and drill holes in floor for bracket. Attach bracket to floor with rivets.

