



Assembly Instructions

Cube Lift Kit

Rev. 1 dd. 13-06-2014

ASSEMBLY ISTRUCTIONS CUBE LIFT KIT



Fix the threaded bar into the lower bracket (prepare all threaded bars).

Use threadlocker during assembly.



Drilling roof into the 4 corners (center of mark).

Make a hole $\varnothing 20\text{mm}$



ARMAL srl Unipersonale

Società soggetta a direzione e coordinamento di Porta Romana 1 s.r.l.

Via Fiorentina, 109 - 50052 Certaldo (FI)

C.F./P.Iva 03922500487 - Cap.Soc. Euro 10.400,00 i.v. - N° REA FI399675

Phone + 39 0571 665305 - Fax +39 0571 651 260

armal@armal.biz - info@cert.armal.biz - www.armal.biz

ISO 9001

BUREAU VERITAS
Certification



Sistema Qualità Certificato
Nr. IT248874

Armal

Assembly Instructions

Cube Lift Kit

Rev. 1 dd. 13-06-2014



Insert threaded bar into the hole under the bathroom



Make the threaded bar upside bathroom and insert the upper bracket



Armal

ARMAL srl Unipersonale

Società soggetta a direzione e coordinamento di Porta Romana 1 s.r.l.
Via Fiorentina, 109 - 50052 Certaldo (FI)
C.F./P.Iva 03922500487 - Cap.Soc. Euro 10.400,00 i.v. - N° REA FI399675
Phone + 39 0571 665305 - Fax +39 0571 651 260
armal@armal.biz - info@cert.armal.biz - www.armal.biz

ISO 9001
BUREAU VERITAS
Certification



Sistema Qualità Certificato
Nr. IT248874



Assembly Instructions

Cube Lift Kit

Rev. 1 dd. 13-06-2014



Fix the eyebolt into the threaded bar.

Attention : Do not tighten too much, just that the ring base touch the plate.

Use threadlocker during assembly



Drilling bathroom (see the hole into the bracket).

Make the operation for all brackets.



ARMAL srl Unipersonale

Società soggetta a direzione e coordinamento di Porta Romana 1 s.r.l.
Via Fiorentina, 109 - 50052 Certaldo (FI)
C.F./P.Iva 03922500487 - Cap.Soc. Euro 10.400,00 i.v. - N° REA FI399675
Phone + 39 0571 665305 - Fax +39 0571 651 260
armal@armal.biz - info@cert.armal.biz - www.armal.biz



Sistema Qualità Certificato
Nr. IT248874



Assembly Instructions
Cube Lift Kit
Rev. 1 dd. 13-06-2014



Complete the operations with fixed
the rivets in all bracket.



Install the sticker in the roof



ARMAL srl Unipersonale
Società soggetta a direzione e coordinamento di Porta Romana 1 s.r.l.
Via Fiorentina, 109 - 50052 Certaldo (FI)
C.F./P.Iva 03922500487 - Cap.Soc. Euro 10.400,00 i.v. - N° REA FI399675
Phone + 39 0571 665305 - Fax +39 0571 651 260
armal@armal.biz - info@cert.armal.biz - www.armal.biz





Assembly Instructions
Cube Lift Kit
Rev. 1 dd. 13-06-2014

CUBE LIFT KIT

User Guide

- Use the four eyebolt (photo) for catch WC



- Lift WC with chains (see photo on the right)

ATTENTION : Lift WC with Empty tank



WARNING



Don't lift WC with people inside



Don't lift WC with full tank



Correct : lift WC with empty tank



ARMAL srl Unipersonale
Società soggetta a direzione e coordinamento di Porta Romana 1 s.r.l.
Via Fiorentina, 109 - 50052 Certaldo (FI)
C.F./P.Iva 03922500487 - Cap.Soc. Euro 10.400,00 i.v. - N° REA FI399675
Phone + 39 0571 665305 - Fax +39 0571 651 260
armal@armal.biz - info@cert.armal.biz - www.armal.biz

